

IOGEAR GPSU21W5 Printer Compatible list

Printer Manufacture	Printer Model	Type of Printer	GPSU21W5
* Only printing function is supported for Multi-Function Printers.			
HP	Business InkJet 1000		OK
HP	Color Laserjet 1500L		OK
HP	Color Laserjet 1600	GDI(USB)	OK
HP	Color Laserjet 2500	Parallel/USB (PCL6/5C)	OK
HP	Color LaserJet 2550	PCL6/PS level 3 (USB)	OK
HP	Color LaserJet 2550L/LN	PCL6/PS level 3 (USB)	OK
HP	Color LaserJet 2600		OK
HP	Color LaserJet 2605	PCL6/5E(USB)	OK
HP	Color LaserJet 2700n	USB2.0	OK
HP	Color LaserJet 2840		OK
HP	Color LaserJet 3700	PCL6/5C(USB,Parallel)	OK
HP	Color LaserJet 4000		
HP	Color LaserJet 4100		
HP	Color LaserJet 4500		
HP	Color Laserjet 4650	Install PCL Driver	OK
HP	Color LaserJet 8550 Color Laser	Parallel (PCL5C)	
HP	Color Laserjet CP1215		OK
HP	Color Laserjet CM1312 MFP	USB	OK
HP	Color Laserjet CM1015 MFP		OK
HP	Designjet 100		OK
HP	Designjet 600		
HP	Designjet 650C		
HP	Designjet 700		
HP	Designjet 750C+		
HP	DeskJet 1120C	Parallel (PCL3)	
HP	Deskjet 1125C	Parallel/USB (PCL3)	OK
HP	Deskjet 1180C	Parallel/USB	OK
HP	DeskJet 1280	PCL3(USB/Parallel)	OK
HP	Deskjet 2000 J210		OK
HP	Deskjet 3000		OK
HP	Deskjet 3050	USB2.0	OK
HP	Deskjet 3325	USB	OK
HP	DeskJet 3420	USB	OK
HP	Deskjet 3535		OK
HP	Deskjet 3650		OK
HP	Deskjet 3743		OK
HP	Deskjet 3748	USB	OK
HP	Deskjet 3820	USB2.0/Parallel	OK
HP	DeskJet 3920		OK
HP	DeskJet 3940		OK

IOGEAR GPSU21W5 Printer Compatible list

Printer Manufacture	Printer Model	Type of Printer	GPSU21W5
* Only printing function is supported for Multi-Function Printers.			
HP	DeskJet 400/420	Parallel	/
HP	Deskjet 450C		OK
HP	DeskJet 5440		OK
HP	DeskJet 5500		/
HP	Deskjet 5550	USB/Parallel	OK
HP	Deskjet 5652	USB/Parallel	OK
HP	Deskjet 670C	Parallel(PCL3)	/
HP	Deskjet 680C		/
HP	Deskjet 720C	Parallel	/
HP	Deskjet 810C	USB2.0/Parallel(PCL3)	OK
HP	Deskjet 830C		OK
HP	Deskjet 845C	USB(PCL3)	OK
HP	DeskJet 9300	USB/Parallel(PCL3)	OK
HP	Deskjet 948c	Parallel/USB	OK
HP	Deskjet 9600		OK
HP	Deskjet 9650	USB/Parallel(PCL3)	OK
HP	Deskjet 970c XI	Parallel/USB(PCL3)	OK
HP	Deskjet 9800	USB/Parallel	OK
HP	Deskjet D1560		OK
HP	Deskjet D2560		OK
HP	Deskjet D5560	USB	OK
HP	DeskJet F370		OK
HP	DeskJet F380		OK
HP	DeskJet F4185		OK
HP	DeskJet F4280		OK
HP	Deskjet F4480	USB	OK
HP	Laserjet M1005 MFP		OK
HP	LaserJet 1022	USB(GDI)	OK
HP	LaserJet 1022N		OK
HP	Laserjet 1100	Parallel	/
HP	Laserjet 1010	USB	OK
HP	LaserJet 1160	USB(PCL5e/GDI)	OK
HP	LaserJet 1200	USB/Parallel (PCL6/5e)	OK
HP	LaserJet 1220		OK
HP	Laserjet 1300	USB/Parallel(PCL6/5e)	OK
HP	Laserjet 1320	USB/Parallel(PCL6/5e)	OK
HP	Laserjet M1522n MFP		OK
HP	LaserJet 2100	Parallel (PCL6)	/
HP	Laserjet 2200d	USB/Parallel	OK
HP	Laserjet 2300	USB/Parallel(PCL6/5E)	OK

IOGEAR GPSU21W5 Printer Compatible list

Printer Manufacture	Printer Model	Type of Printer	GPSU21W5
* Only printing function is supported for Multi-Function Printers.			
HP	LaserJet 2410	PCL6/5E(USB)	OK
HP	LaserJet 2420	USB/Parallel(PCL6/5E)	OK
HP	LaserJet 2550		OK
HP	LaserJet 3015	USB/Parallel(PCL6/5E)	OK
HP	LaserJet 3050	USB(PCL6/PCL5E)	OK
HP	LaserJet 3055		OK
HP	Laserjet 3200	USB/Parallel(PCL6/5E)	OK
HP	Laserjet 3330		OK
HP	LaserJet 3330mfp	USB/Parallel (PCL6/5E)	OK
HP	LaserJet 3380	USB/Parallel (PCL6/5E)	OK
HP	Laserjet 4000	Parallel(B.C)	
HP	LaserJet 4050	Parallel(PCL6/5e)	
HP	Laserjet 4100 /4100n	Parallel (PCL6/5E)	
HP	LaserJet 4250	USB/Parallel(PCL6/5E)	OK
HP	Laserjet 4300n	Parallel (PCL6/5E)	
HP	Laserjet 4300tn/dtn	Parallel (PCL6/5E)	
HP	Laserjet 4500		
HP	Laserjet 4650		OK
HP	Laserjet 5100fn/tn	Parallel (PCL6/5E)	
HP	Laserjet 5100le/se	Parallel (PCL6/5E)	
HP	Laserjet 6P / 6L	Parallel	
HP	Laserjet 8100		
HP	Laserjet M1005		OK
HP	Laserjet M1005 MFP		OK
HP	Laserjet M1120 MFP		OK
HP	LaserJet M1319F MFP	USB	OK
HP	LaserJet P2015	USB(PCL6/5e/PS Level 3	OK
HP	Officejet J3608		OK
HP	OfficeJet 4255		OK
HP	OfficeJet 4255		OK
HP	Officejet 4500		OK
HP	OfficeJet 5610	USB	OK
HP	Officejet J5780		OK
HP	OfficeJet 6210		OK
HP	OfficeJet 6310	USB	OK
HP	Officejet 6000	USB	OK
HP	Officejet 6500		OK
HP	Officejet 7000	USB	
HP	Officejet 7500A	USB2.0	OK
HP	OfficeJet 7210		OK

IOGEAR GPSU21W5 Printer Compatible list

Printer Manufacture	Printer Model	Type of Printer	GPSU21W5
* Only printing function is supported for Multi-Function Printers.			
HP	OfficeJet J4580		OK
HP	Officejet J4660		OK
HP	Officejet J6480		OK
HP	Officejet K7100		OK
HP	OfficeJet K850		OK
HP	OfficeJet Pro K5300		OK
HP	OfficeJet Pro K550		OK
HP	OfficeJet Pro K8600		OK
HP	Officejet Pro L7380		OK
HP	Officejet Pro L7590		OK
HP	Officejet Pro 6500A Plus	USB2.0	OK
HP	Officejet Pro 7000		OK
HP	Officejet Pro 8000	USB	OK
HP	Officejet Pro 8500A Plus	USB2.0	OK
HP	Officejet Pro 8500W		OK
HP	Photosmart 2610		OK
HP	Photosmart 3110		OK
HP	Photosmart 7150	USB2.0	OK
HP	Photosmart 7200		OK
HP	Photosmart 7550	USB 2.0 、 Parallel	OK
HP	Photosmart 7660	USB(PCL3)	OK
HP	Photosmart 7830		OK
HP	Photosmart 7900		OK
HP	Photosmart 8200		OK
HP	Photosmart Plus B209a	USB	OK
HP	Photosmart Plus B210a	USB	OK
HP	Photosmart Plus C310a	USB	OK
HP	Photosmart A520		OK
HP	Photosmart B109a		OK
HP	Photosmart B110a AIO		OK
HP	Photosmart C309a		OK
HP	Photosmart C410a	USB2.0	OK
HP	Photosmart C3180		OK
HP	Photosmart C4180		OK
HP	Photosmart C4280		OK
HP	Photosmart C4385		OK
HP	Photosmart C4480		OK
HP	Photosmart C4580		OK
HP	Photosmart C5180		OK
HP	Photosmart C5280		OK

IOGEAR GPSU21W5 Printer Compatible list

Printer Manufacture	Printer Model	Type of Printer	GPSU21W5
* Only printing function is supported for Multi-Function Printers.			
HP	Photosmart C5380		OK
HP	Photosmart C6180		OK
HP	Photosmart C6280		OK
HP	Photosmart C6380		OK
HP	Photosmart C7180		OK
HP	Photosmart C7280		OK
HP	Photosmart C8180		OK
HP	Photosmart D5160		OK
HP	Photosmart D5360		OK
HP	Photosmart D5460		OK
HP	Photosmart D7160		OK
HP	Photosmart D7260		OK
HP	Photosmart D7360		OK
HP	Photosmart Premium C309g		OK
HP	Photosmart Premium C310g		OK
HP	PSC 1210	USB 2.0	
HP	PSC 1315		OK
HP	PSC 1350	USB (LIDIL)	OK
HP	PSC 1410		OK
HP	PSC 1610		OK
HP	PSC 2210		OK
HP	PSC 2310	USB	OK
EPSON	Aculaser C1100SE		OK
EPSON	Aculaser C1700	USB	OK
EPSON	Aculaser C1750N	USB	OK
EPSON	Aculaser C1750W	USB	OK
EPSON	Aculaser C1900	USB/Parallel	OK
EPSON	Aculaser C2900	USB	OK
EPSON	Aculaser C3800	USB	OK
EPSON	Aculaser C3900N	USB	OK
EPSON	Aculaser C9100		OK
EPSON	Aculaser CX16NF	USB	OK
EPSON	Aculaser CX17NF	USB	OK
EPSON	Aculaser M1400	USB	OK
EPSON	Aculaser M2010DN		OK
EPSON	Aculaser M2010D		OK
EPSON	Aculaser M2310D	USB/Parallel	OK
EPSON	Aculaser M2310DN	USB	OK
EPSON	Aculaser M2410D	USB/Parallel	OK
EPSON	Aculaser M2410DN	USB	OK

IOGEAR GPSU21W5 Printer Compatible list

Printer Manufacture	Printer Model	Type of Printer	GPSU21W5
* Only printing function is supported for Multi-Function Printers.			
EPSON	Aculaser MX14	USB	OK
EPSON	Aculaser MX14NF	USB	OK
EPSON	B-508DN		OK
EPSON	C750		OK
EPSON	CC-500L		OK
EPSON	CL-760		OK
EPSON	E-300L		OK
EPSON	E-520		OK
EPSON	E-720		OK
EPSON	EC-01		OK
EPSON	EPL 5700		/
EPSON	EPL 5700	Parallel (ESC/Pages)	/
EPSON	EPL 5800		OK
EPSON	EPL 5800	USB/Parallel (PCL6/5e)	OK
EPSON	EPL 5900		OK
EPSON	EPL 5900	USB/Parallel	OK
EPSON	EPL 6100	USB/Parallel (PCL6/5e)	OK
EPSON	EPL 6200		OK
EPSON	Aculaser C1600		OK
EPSON	B-518DN		OK
EPSON	EPL 6200	USB/Parallel (ESC/Pages)	OK
EPSON	EPL N2120		/
EPSON	K100	USB	OK
EPSON	L200	USB	OK
EPSON	L800	USB	OK
EPSON	LP2500		OK
EPSON	LP-7700		OK
EPSON	LP-8700		OK
EPSON	LP-8800C		OK
EPSON	LP8900		OK
EPSON	LP-9500C		OK
EPSON	LQ 100		/
EPSON	LQ 1000C		/
EPSON	LQ 1170+		/
EPSON	LQ 1170C		/
EPSON	LQ 1170C+		/
EPSON	LQ 2070C		/
EPSON	LQ 2080C		/
EPSON	LQ 2090		/
EPSON	LQ 2090C		OK

IOGEAR GPSU21W5 Printer Compatible list

Printer Manufacture	Printer Model	Type of Printer	GPSU21W5
* Only printing function is supported for Multi-Function Printers.			
EPSON	LQ 2170C	Parallel(ESC/P)	
EPSON	LQ 2180C		
EPSON	LQ 2190C	Parallel/USB	OK
EPSON	LQ 2550		
EPSON	LQ 300	Parallel(ESC/P)	
EPSON	LQ 300+		
EPSON	LQ 300+II		OK
EPSON	LQ 3500C		
EPSON	LQ 570C		
EPSON	LQ 670		
EPSON	LQ 680	Parallel(ESC/P)	
EPSON	LQ 680C		
EPSON	ME 320		OK
EPSON	ME 340	USB	OK
EPSON	ME Office 82WD	USB	OK
EPSON	ME Office 900WD	USB	OK
EPSON	ME Office 940FW	USB	OK
EPSON	ME Office 960FWD	USB	OK
EPSON	MC-2000		OK
EPSON	PictureMate PM250		OK
EPSON	PLQ-20C		OK
EPSON	PLQ-20CM		OK
EPSON	PM-860PT		OK
EPSON	PM-890C		OK
EPSON	PM-920C		OK
EPSON	PM-930C		OK
EPSON	PM-950C		OK
EPSON	PM-970C		OK
EPSON	PM-980C		OK
EPSON	PM-A550		OK
EPSON	PM-A620		OK
EPSON	PM-A650		OK
EPSON	PM-A720		OK
EPSON	PM-A820		OK
EPSON	PM-A840		OK
EPSON	PM-A850		OK
EPSON	PM-A890		OK
EPSON	PM-A900		OK
EPSON	PM-A920		OK
EPSON	PM-A940		OK

IOGEAR GPSU21W5 Printer Compatible list

Printer Manufacture	Printer Model	Type of Printer	GPSU21W5
* Only printing function is supported for Multi-Function Printers.			
EPSON	PM-A950		OK
EPSON	PM-A970		OK
EPSON	PM-2200C		OK
EPSON	PM-3500C		OK
EPSON	PM-3700C		OK
EPSON	PM-4000PX		OK
EPSON	PM-D800		OK
EPSON	PM-D870		OK
EPSON	PM-D1000		OK
EPSON	PM-FA700		OK
EPSON	PM-G800		OK
EPSON	PM-G820		OK
EPSON	PM-G850		OK
EPSON	PM-G860		OK
EPSON	PM-G4500		OK
EPSON	PM-T960		OK
EPSON	PM-T990		OK
EPSON	PX-5000		OK
EPSON	PX-A640		OK
EPSON	PX-A740		OK
EPSON	PX-G5300		OK
EPSON	PX-G5100		OK
EPSON	PX-G930		OK
EPSON	PX-G5000		OK
EPSON	PX-V780		OK
EPSON	RX 510		OK
EPSON	RX 530		OK
EPSON	RX 590		OK
EPSON	RX 630		OK
EPSON	RX 690		OK
EPSON	Stylus C20		OK
EPSON	Stylus C40		OK
EPSON	Stylus C41UX/SX	USB	OK
EPSON	Stylus C43UX		OK
EPSON	Stylus C45		OK
EPSON	Stylus C59		OK
EPSON	Stylus C60	USB/Parallel	OK
EPSON	Stylus C63		OK
EPSON	Stylus C67		OK
EPSON	Stylus C79		OK

IOGEAR GPSU21W5 Printer Compatible list

Printer Manufacture	Printer Model	Type of Printer	GPSU21W5
* Only printing function is supported for Multi-Function Printers.			
EPSON	Stylus C83		/
EPSON	Stylus C90		OK
EPSON	Stylus Color 1160	USB/Parallel	OK
EPSON	Stylus Color 1500		OK
EPSON	Stylus Color 1520		OK
EPSON	Stylus Color 400	Parallel	/
EPSON	Stylus Color 600		/
EPSON	Stylus Color 670	USB/Parallel (ESC/P)	OK
EPSON	Stylus Color 800	Parallel (ESC/P2)	OK
EPSON	Stylus Color 810		OK
EPSON	Stylus Color 850	Parallel (ESC/P2)	OK
EPSON	Stylus Color 900	USB/Parallel (ESC/P2)	OK
EPSON	Stylus CX-1500		OK
EPSON	Stylus CX-2900		OK
EPSON	Stylus CX-3500		OK
EPSON	Stylus CX-3700		OK
EPSON	Stylus CX-3900		OK
EPSON	Stylus CX-4100		OK
EPSON	Stylus CX-4700		OK
EPSON	Stylus CX-4900		OK
EPSON	Stylus CX-5300		OK
EPSON	Stylus CX-5500		OK
EPSON	Stylus CX-5505		OK
EPSON	Stylus CX-5900		OK
EPSON	Stylus CX-6900F		OK
EPSON	Stylus CX-7300		OK
EPSON	Stylus CX-7800		OK
EPSON	Stylus CX-8300		OK
EPSON	Stylus CX-9300F		OK
EPSON	Stylus Office T30		OK
EPSON	Stylus Office T40W	USB	OK
EPSON	Stylus Office TX300F		OK
EPSON	Stylus Office TX320F	USB	OK
EPSON	Stylus Office TX510FN	USB	OK
EPSON	Stylus Office TX600FW		OK
EPSON	Stylus Office TX610FW	USB	OK
EPSON	Stylus Office T1100	USB	OK
EPSON	Stylus Photo 915		OK
EPSON	Stylus Photo 1270	USB/Parallel	OK
EPSON	Stylus Photo 1290	USB/Parallel	OK

IOGEAR GPSU21W5 Printer Compatible list

Printer Manufacture	Printer Model	Type of Printer	GPSU21W5
* Only printing function is supported for Multi-Function Printers.			
EPSON	Stylus Photo 1390		OK
EPSON	Stylus Photo 2100		OK
EPSON	Stylus Photo 710	USB/Parallel	OK
EPSON	Stylus Photo 720	USB/Parallel	OK
EPSON	Stylus Photo 790		OK
EPSON	Stylus Photo 810		OK
EPSON	Stylus Photo 830U		OK
EPSON	Stylus Photo 900		OK
EPSON	Stylus Photo 915		OK
EPSON	Stylus Photo EX2	Parallel	OK
EPSON	Stylus Photo EX3	Parallel/USB1.1	OK
EPSON	Stylus Photo R1800		OK
EPSON	Stylus Photo R210	USB1.1	OK
EPSON	Stylus Photo R230	USB	OK
EPSON	Stylus Photo R250	USB	OK
EPSON	Stylus Photo R270	ESC/P(USB)	OK
EPSON	Stylus Photo R310	USB2.0	OK
EPSON	Stylus Photo R350		OK
EPSON	Stylus Photo R2400	USB	OK
EPSON	Stylus Photo R800		OK
EPSON	Stylus Photo RX430	USB	OK
EPSON	Stylus Photo RX 510		OK
EPSON	Stylus Photo RX 530		OK
EPSON	Stylus Photo RX 590		OK
EPSON	Stylus Photo RX 630		OK
EPSON	Stylus Photo RX 650		OK
EPSON	Stylus Photo RX 690		OK
EPSON	Stylus Photo R2880		OK
EPSON	Stylus Photo TX700W	USB	OK
EPSON	Stylus Photo TX800FW	USB	OK
EPSON	Stylus Photo TX820FWD	USB	OK
EPSON	Stylus Pro 7600	USB/Parallel	OK
EPSON	Stylus TX550W	USB	OK
EPSON	Stylus TX420W		OK
EPSON	Stylus TX410	USB	OK
EPSON	Stylus TX430	USB	OK
EPSON	Stylus TX235	USB	OK
EPSON	Stylus TX220		OK
EPSON	Stylus TX200	USB	OK
EPSON	Stylus TX210	USB	OK

IOGEAR GPSU21W5 Printer Compatible list

Printer Manufacture	Printer Model	Type of Printer	GPSU21W5
* Only printing function is supported for Multi-Function Printers.			
EPSON	Stylus TX130	USB	OK
EPSON	Stylus TX110	USB	OK
EPSON	Stylus TX100	USB	OK
EPSON	Stylus T22		OK
EPSON	Stylus T20	USB	OK
EPSON	Stylus T21	USB	OK
EPSON	Stylus Photo T50	USB	OK
EPSON	TM883 (III)		
EPSON	TM T88III		
Canon	BJ-330		
Canon	BJC-4200		
Canon	BJC-4300	Parallel	
Canon	BJC-4500	Parallel	
Canon	BJC-4550	Parallel	
Canon	BJC-4600		
Canon	BJF9000		OK
Canon	D380		OK
Canon	I-255		OK
Canon	I-355		OK
Canon	I-450		OK
Canon	I-455		OK
Canon	I-470D		OK
Canon	I-475D		OK
Canon	I-550		OK
Canon	I-560		OK
Canon	I-850	IEEE 1284/USB	OK
Canon	I-865		OK
Canon	I-950	USB 2.0	OK
Canon	I-6100		OK
Canon	I-6500		OK
Canon	I-9100		OK
Canon	I-9950		OK
Canon	IX4000		OK
Canon	IX5000		OK
Canon	Imageclass D380		OK
Canon	MP-160		OK
Canon	MP-638		OK
Canon	MP 770		OK
Canon	MX318		OK
Canon	MX320		OK

IOGEAR GPSU21W5 Printer Compatible list

Printer Manufacture	Printer Model	Type of Printer	GPSU21W5
* Only printing function is supported for Multi-Function Printers.			
Canon	MX700		OK
Canon	PIXUS IP2500		OK
Canon	PIXUS 990i		OK
Canon	PIXMA iP1000	USB1.1	OK
Canon	PIXMA iP1700		OK
Canon	PIXMA iP1800		OK
Canon	PIXMA Ip1880	USB	OK
Canon	PIXMA Ip1980		OK
Canon	PIXMA Ip2000		OK
Canon	PIXMA iP3000	USB 2.0	OK
Canon	PIXMA Ip3300		OK
Canon	PIXMA Ip3500	USB	OK
Canon	PIXMA Ip3680	USB	OK
Canon	PIXMA iP4000	USB1.1/IEEE1284	OK
Canon	PIXMA Ip4200		OK
Canon	PIXMA Ip4300		OK
Canon	PIXMA Ip4500		OK
Canon	PIXMA Ip4760		OK
Canon	PIXMA Ip5000		OK
Canon	PIXMA Ip6000		OK
Canon	PIXMA Ip8500		OK
Canon	PIXMA MG6170	USB2.0	OK
Canon	PIXMA MP110	USB	OK
Canon	PIXMA MP130		OK
Canon	PIXMA MP145		OK
Canon	PIXMA MP150	USB 2.0 (GDI)	OK
Canon	PIXMA MP180		OK
Canon	PIXMA MP258	USB	OK
Canon	PIXMA MP450		OK
Canon	PIXMA MP730		OK
Canon	PIXMA MP780		OK
Canon	PIXMA MP830		OK
Canon	PIXMA MX357		OK
Canon	PIXMA MX416	USB2.0	OK
Canon	S-200SPX		OK
Canon	S-520	Parallel/USB	/
Lexmark	C720	Parallel	/
Lexmark	E230	Parallel/USB2.0	OK
Lexmark	E322	USB	OK
Lexmark	Optra S1250	Parallel	/

IOGEAR GPSU21W5 Printer Compatible list

Printer Manufacture	Printer Model	Type of Printer	GPSU21W5
* Only printing function is supported for Multi-Function Printers.			
Lexmark	P4350		OK
Lexmark	P6250		OK
Lexmark	T420		OK
Lexmark	T620		OK
Lexmark	W812	USB1.1/Parallel	OK
Lexmark	Z42		OK
Lexmark	Z43	USB	OK
Lexmark	Z45	USB	OK
Lexmark	Z55		OK
Lexmark	Z515		OK
Lexmark	Z615	USB1.1	OK
Lexmark	Z705		OK
FUJI Xerox	Able 3321		
FUJI Xerox	DL700		
FUJI Xerox	DL900		
FUJI Xerox	DL-3400		
FUJI Xerox	DL-3800		
FUJI Xerox	DL-3850		
FUJI Xerox	DL-5800		
FUJI Xerox	DL-6400Pro		
FUJI Xerox	DL-6800		
FUJI Xerox	DocuPrint 2050	GDI(USB/Parallel)ok	OK
FUJI Xerox	DocuPrint 240A		OK
FUJI Xerox	DocuPrint C1110B		OK
FUJI Xerox	DocuPrint CM205 f	USB	OK
FUJI Xerox	DocuPrint CP105 b	USB	OK
FUJI Xerox	DocuPrint P205 b	USB2.0	OK
FUJI Xerox	DocuPrint M205 b	USB	OK
FUJI Xerox	DocuPrint M205 f	USB	OK
FUJI Xerox	DocuPrint M205 fw	USB	OK
FUJI Xerox	FP 410		
FUJI Xerox	Jet Wind 500C		
FUJI Xerox	Phaser 3310		OK
FUJI Xerox	PP 10		
Konica Minolta	Di 152	PCL-5	
Konica Minolta	Di 200/Di 250/Di 251	PCL-5	
Konica Minolta	magicolor 2450	USB (PCL-5)	OK
Konica Minolta	magicolor 5450	USB/Parallel (PCL-5)	OK
Konica Minolta	magicolor 7300		OK
Konica Minolta	Magicolor 7300	IEEE1284/USB1.1	OK
Konica Minolta	PagePro 1350W		OK

IOGEAR GPSU21W5 Printer Compatible list

Printer Manufacture	Printer Model	Type of Printer	GPSU21W5
* Only printing function is supported for Multi-Function Printers.			
Konica Minolta	PagePro 9100	IEEE1284/USB1.1	OK
Samsung	CLP-315		OK
Samsung	CLP-500	(SPL)	OK
Samsung	CLP-510		OK
Samsung	CLP-620ND		OK
Samsung	CLX2160	USB	OK
Samsung	ML-1510/1710	(SPL)	OK
Samsung	ML-1520		OK
Samsung	ML-1660		OK
Samsung	ML-1710		OK
Samsung	ML-1750	IEEE1284/USB(PCL6)	OK
Samsung	ML-1915	USB	OK
Samsung	ML-2010	SPL(USB)	OK
Samsung	ML-2250		OK
Samsung	ML-2550		OK
Samsung	ML-2580N		OK
Samsung	ML-3471ND		OK
Samsung	SCX-4016		OK
Samsung	SCX-4100/4106/4116/4216F	IEEE-1284/USB(SPL)	OK
Samsung	SRP 270		
Panasonic	KX-P1121		
Panasonic	KX-P1123		
Panasonic	KX-P1124		
Panasonic	KX-P1624		
Panasonic	KX-P6500		
TOSHIBA	E-161		
	Estudio-25		
NEC	NEC P2200		
	NEC P3200		
	NEC P5300		
	NEC P8000		
IBM	IBM Inforprint 20	IEEE 1284 Parallel	
	Infoprint 1116		OK
	Infoprint 1312		OK
	Infoprint 1316		OK
	Infoprint 1332		OK
	Infoprint 1412		OK
Star	NX-2420		
	AR-255		
	AR-265FG		
	AR-M160(AR-NB2)	IEEE 1284, USB 2.0	

IOGEAR GPSU21W5 Printer Compatible list

Printer Manufacture	Printer Model	Type of Printer	GPSU21W5
* Only printing function is supported for Multi-Function Printers.			
Sharp	AR-M205	IEEE 1284, USB 2.0	
	AR-M207		
	AR-M209	IEEE 1284, USB 2.0	
	AR-M235		
	AR-M236	IEEE 1284, USB 2.0	
	AR-M275		
	AR-M276	IEEE 1284, USB2.0	
	AR-M350		
	AR-M400		
	AR-M450		
RICOH	NF3570		
Brother	MFC 4800		OK
	MFC 4800J		OK
	MFC 6800		OK
	MFC 7220	GDI(USB/Parallel)	OK
	MFC 7420	GDI(USB/Parallel)	OK
	MFC 7820N		OK
	MFC 8840D		OK
	MFC 210C		OK
	MFC 240C		OK
	DCP-7030	USB2.0	OK
	HL1260		
	HL-2040	PCL6(USB,Parallel)	
	HL-2140		OK
	HL-2170W	USB	OK
	IntelliFax 2820		OK
Others	震旦AD-166数码复合机	USB(GDI)	
	震旦AD-216数码复合机	USB口使用1101U(GDI)	
	震旦AD-226数码复合机	USB(GDI)	
	DELL 1100	Parallel/USB(GDI)	
	中崎AB-80K (票据)		
	OKI 5530	Parallel	
	OKI Microline 391		
	OKI B4350		OK
	吉成5890热敏打印机	Parallel	
	MITAC	MP-6600C	
	BENQ CM3000		OK
Avison	MF 3200		OK
	MF 3230		OK
Citizen	GSX230		
DATAMAX	I-4208		
	I-4308		

IOGEAR GPSU21W5 Printer Compatible list

Printer Manufacture	Printer Model	Type of Printer	GPSU21W5
* Only printing function is supported for Multi-Function Printers.			
DOCUJET	1610F		OK
	UA1610		OK
FUTEK	F8000		
	F84+		
	F86+		
Kyocera	FS-1010		OK
	FS-1010KX		OK
	FS-1020		OK
	FS-1920		OK
	FS-2000D		OK
	FS-820		OK
	FS-920		OK
	FS-6020		OK
	FS-6026		OK